


# Allsky Setup Instructions



# Allsky Setup Instructions

## Index

- [Introduction](#)
- [Hardware](#)
- [3-D Printed Components](#)
- [Hardware Assembly Instructions – Raspberry Pi5](#)
- [Pi5 Operating System Installation](#)
- [Remote Access the Pi5 with Secure Shell \(SSH\)](#)
- [Implementing VNC for Remote Desktop Control](#)
- [Setup Samba Server on Pi5](#)
- [AllSky Cam Enclosure Cooling Fan Software Installation](#)
- [Install Gparted Application to Format](#)
- [Backup Pi5 as a Disk Image](#)
- [Remote Website Setup: Sub Domain Setup](#)
  - [Create Directory Structure for Sub Domain](#)
  - [Create the allsky Sub-Domain](#)
  - [Create an Administrator Account to Manage the Sub-Domain](#)
- [Remote Website Setup: Install Remote Website](#)
-

# Allsky Setup Instructions

## Introduction

The Allsky cam is a project that monitors sky conditions by providing live images of the sky for the location the Allsky camera is located. This is done via a website. You can utilize a local website that is available only on the local network or optionally publish the website on the internet so it is available anywhere.

AllSky Cam Example

- [McYoder AllSky-01](#) – Typical Remote installation example
- ArtCentrics Yoder [Site Weather and Conditions webpage](#) – Integration of skycam in website displays the latest camera image along with Astropheric Weather Forecast.

In addition to the immediate sky image the website can also optionally provide the following features:

- **Constellation Overlay** – Display constellation overlay on live view image.
- **Timelapse** – A timelapse video of the previous night.
- **Keograms** – A image that summarizes the sky conditions for the night by building a single image composed of a single row of pixels for each image taken through the night.
- **Startrails** – A image showing the startrails for the previous night.

This document outlines the steps required to create your own Allsky cam. It lists the hardware purchased operating system installation and software installation and configuration.

For this project the Raspberry Pi5 computer was used.

The build procedure for this project in order is:

- Purchase Hardware
- Hardware Assembly
  - Raspberry Pi 5 & Cam
  - Allsky Pipe Enclosure
- Pi5 Operating System Installation
- Installation and Configuration of Supporting Operating System Applications
- Installation and Configuration of the Allsky software
- Remote Website Setup
  - Configuration of Remote Website
  - Configuration and Installation of Allsky Software for Remote Website

This project was a result of a lot of work by the developers of the [Allsky project](#) at Github. Please make a contribution to them to encourage further development!

## References

- YouTube: [All-Sky Raspberry Pi – How my all sky cam works automatically in my backyard](#)
- Patriot Astrophotography: [Build Your Own All Sky Camera](#)

# Allsky Setup Instructions

- Github: [Allsky project](#)
  - [Allsky Documentation](#)
  - [Discussions](#)
  - [Issues](#)
- Autodesk Instructables: [Wireless All Sky Camera](#)
- Raspberry Pi5
  - [Raspberry Pi OS](#)

DRAFT

# Allsky Setup Instructions

## Hardware

Provided below is a summary of the hardware purchased to create the Allsky camera. In addition to the listed hardware the housing (PVC/ABS piping) for the Allsky cam needs to be purchased from your local hardware store.

### Computer and Supporting Hardware

Item	Cost	Comments
RasTech Raspberry Pi 5 8GB Kit 64GB Edition	<a href="#">\$130</a>	Latest version of Raspberry boards as of 2024-11-14. Comes with 64GB card but used higher capacity card. Raspberry Pi OS (64 bit): Debian Bookworm (2024-10-22 Release)
ScanDisk 256 GB MicroSDXC UHS-I Card	<a href="#">\$45</a>	Large capacity card - Optional
Noctua NF-A4x10 5V PWM, Premium Quiet Fan	<a href="#">\$15</a>	Article on installation and software <a href="#">here</a> .
Gigabite USB Type C Active PoE Splitter	<a href="#">\$13</a>	Option to eliminate P33 Hat if you don't want to purchase the hat.
60W Gigabite PoE++ Injector	<a href="#">\$30</a>	Required for utilizing Power over Ethernet for the P33 Hat
Arducam for Raspberry Pi HW Camera, 12.3 MP IMX477	<a href="#">\$50</a>	Will require minor configuration changes as detailed in instructions since this is a third party vendor.
Arducam M12 Lens Kit for Raspberry Pi HQ camera	<a href="#">\$100</a>	This lens kit is overkill for what we need, but purchased a single lens, and it didn't fit because it needed a CS-Mount adapter. This kit includes the adapter.
1.56mm f/2.0 5MP HD fisheye lens	<a href="#">\$15</a>	This lens needs a CS to M12 mount adapter to use
CS to M12 Mount Lens Converter Adapter	<a href="#">\$2</a>	This item takes a long time to ship.
Solid State Drive (256GB)	<a href="#">\$20</a>	Can replace Micro SDXC card but requires Geek Pi P33 addition to Basic Pi 5
<b>Total</b>	<b>\$xxx</b>	

### Allsky Cam Enclosure (Hardware Store Purchases)

Item	Cost	Comments
3" PVC/ABS Pipe	<a href="#">\$13</a>	
PVC Pipe End Cap	<a href="#">\$4</a>	
PVC Cleanout Adapter with Cleanout Plug	<a href="#">\$12</a>	
3.3" Acrylic Dome	<a href="#">\$15</a>	
Dielectric Silicone Crease	<a href="#">\$12</a>	Use on ethernet connection outdoors

# Allsky Setup Instructions

## 3-D Printed components

Various 3D printed components were developed for this project and are identified below.

- **Templates** – These are created to place over appropriate components to identify drill and cut areas.
  - **Bottom Template**- This may have been replaced with the Screw Plate Template below; need to verify that.
  - **Dome Gasket Template** – Placed over PVC pipe end cap, these holes identify where to drill holes for screws holding down the plastic dome covering the camera. These also match with the holes in the gasket for the dome.
  - **Screw Plate Template** - Template place in the bottom screw in plug for the PVC pipe. These are vent holes. NOTE that you will also need to cut a center hole for the POE cable that is not identified in this template. Note the hole at the edge is for reference for alignment and should not be drilled.
  - **Top Template** – This template is placed over the top end-cap of the PVC pipe and identifies what holes need to be drilled to hole the camera, plastic dome, and vent holes to keep the dome from fogging. Note the large hole is just a trace hole used to identify where the small bubble level can go. NOTE: Need to verify the placement of the 4 camera holes and that they are in the proper location.
- **Bug Screen** – Thin plate used to attach bug screen to. Center hole the passthrough for the short Ethernet cable used to connect the Pi 5 to the POE Ethernet line. Note the connector must be added after the cable is passed through the hole.
- **Compass Mount** – A mini compass holder that grabs onto the PVC pipe so you can orient the camera North.
- **Dome Gasket** – Gasket used to keep water out, it is place between the platic dome and the PVC endcap. Printed with TPY filament.
- **Mount** – Used to attach AllSky PVC pipe setup to pole.
- **Platform** – This piece goes between the Bug Screen and the PVC bottom screw in plug and is what the Pi 5 will sit on.
- **Stand** – A stand to place the AllSky /PVC rig while working on it so it doesn't have to lie on the side.
- **Top Spacer** – Not currently being used, but designed for placement in the body of the PVC pipe between the top endcap(holing the camera) and the Pi 5 to make sure the Pi 5 doesn't rattle around during transport. Currently excess cables go in this area and it appears this may not be needed.
- **Vent** – This series of pieces are used to house the fan that is utilized to draw hot air out of the PVC body to keep the Pi 5 from overheating. Note a bug screen need to be place in here also


# Allsky Setup Instructions

## Hardware Assembly Instructions – Raspberry Pi5

Assembly is pretty simple, follow assembly instructions that come with the Raspberry Pi5 and add the Arducam camera with the fish eye lens. Pay particular attention to the orientation for the data ribbon between the Pi5 and the camera (see images below), if not installed in the proper orientation or seated in the connection correctly the camera will not be accessible for the Pi5 computer.

The following additional components will be added to the base Pi5 system:

- Arducam for Raspberry Pi HW Camera
- Noctua NF-A4x10 5V PWM, Premium Quiet Fan – This fan will help cool the AllSky cam enclosure.



# Allsky Setup Instructions

Note: Instructions on installation of the baseline operating system (Debian Bookworm) along with configuration details and subsequent supporting applications along with installation of the Skycam application is provided in this document. However, I will take an image of a system that has the OS, supporting applications and basic Allsky cam installed already, so that really all one should have to do is install the stored image and make configuration changes to get to the point where the local Allsky website is working.



# Allsky Setup Instructions

## Pi5 Operation System Installation

Installation of the Pi 5 Operating system is accomplished by flashing the memory card with a PC utilizing the Raspberry Pi Imager application.

- Insert the SD card that will contain the Pi5 Operating System in the PC.
- Start the [Raspberry Pi OS Imager](#) application
  - Choose Device: Raspberry Pi 5
  - Operating System: Raspberry Pi OS (64-bit)
  - Choose Storage: Select the SD Card that will be used for the Pi 5
  - Select the [Next] button to continue
  - Use OS customization?
    - Select [Edit Settings]
      - [GENERAL] tab
        - Set hostname: **AllSky-01.local**
        - Username: {*YourUserName*}
        - Password: {*YourPassword*}
        - Configure Wireless LAN
          - SSID: {*YourWiFi*}
          - Password: {*WiFiPassword*}
        - Wireless LAN country: **US**
        - Set local settings
          - Time zone: **America/Phoenix**
          - Keyboard Layout: **us**
      - [SERVICES] tab
        - Enable SSH: {*Checked*}
        - Use password authentication: {*Checked*}
      - Select [SAVE] to save settings and return back to the previous menu
    - Would you like to apply OS customisations settings?
      - Select [YES] to continue
    - Data warning is displayed to make sure you want to overwrite the SD card. Select **YES** to continue
    - Once the data has all been written to the SD card you will get a message that it has been completed. You can then shutdown the application and remove the SD card from the PC and insert it into the Pi5.
- DONE

### References

- Raspberrypi.com: [Raspberry Pi OS Imager](#)

# Allsky Setup Instructions

## Remote Access the Pi5 with Secure Shell (SSH)

You don't have to be physically in front of your Pi5 to configure it. There are three means of connecting to your Pi5 remotely (see references below). Here we will utilize the Secure Shell (SSH) method since it doesn't require any installation of software on the Pi5 (we already enabled SSH in the [Pi5 Operating System Installation](#) procedure and SSH is included in the Windows Operating System under the Command Shell.

- Make sure you Pi5 is powered and connected to your local network.
- On the Windows PC
  - Make sure the Window PC is on the same network as the Pi5
  - Start the Command Prompt application
  - At the command line enter the SSH command to connect to the Pi5
    - SSH `{YourUserName}@AllSky-01.local`
      - You should be prompted for the password selected when creating the Pi5 operating system image.
      - Note: as you type the password it will not be displayed
      - After entering the password you should have a prompt that looks like this:
        - `{YourUserName}@AllSky-01:~$`
      - You have now remoted into the Pi5 system and it is ready to receive commands
      - When completed and ready to log out of the Pi5 enter
        - Exit
          - You will be returned to the Windows Prompt
    - You can now exit the windows shell application
      - Exit
- DONE

### References

- Raspberrypi.com: [Remote Access](#)

# Allsky Setup Instructions

## Implementing VNC for Remote Desktop Control

Another way to connect to the Pi 5 besides utilizing Secure Shell Method (SSH) is through Virtual Network Computing (VNC) where you can manage your Pi5 through a desktop interface. VNC is part of the Bookworm operating system in the Pi5, but needs to be enabled. Additionally, a VNC program must be installed on the external computer to access the Pi5 through VNC.

Note: *It is assumed that the PC and the Pi5 are residing on the same network for these applications to communicate.*

### Enable VNC on Pi5

- Remote into the Pi 5
- Execute the raspi-config program  
    Sudo raspi-config
- Select Interface Options menu item  
    3 Interface Options Configure connections to peripherals
- Select I3 VNC menu item  
    I3 VNC Enable/disable graphical remote desktop access
- Would you like the VNC Server to be enabled?  
    <Yes>
- Confirmation Message
  - The VNC Server is enabled  
    <ok>
- Back at the main menu select <Finish> to exit and be returned to the command line  
    <Finish>
- DONE with the Pi5 Configuration!

### Install VNC application on your computer

There are a number of VNC applications you can use to access your Pi5. I utilize the [TigerVNC](#) (free) application

- Visit the [GitHub website](#) to download the latest TigerVNC version for your operating system.
- Follow the installation instructions.
- Connecting to the Pi5 through VNC will utilize the same login credentials as you do with SSH.
- DONE!

### References:

- Raspberrypi.com: [Remote Access](#)
- [TigerVNC viewer](#) website
- GitHub [TigerVNC project webpage](#)

# Allsky Setup Instructions

## Setup Samba Server on Pi5

Setting up a Samba server on the Pi5 will allow you to access the user directory on the Pi5 through your home network so you can access files on your local computer once you map the drive.

- Remote into the Pi 5
- Install Samba Server on Pi 5
  - `sudo apt install samba samba-common-bin`
- Configure Samba on the Pi 5
  - `sudo nano /etc/samba/smb.conf`
- Update Samba Configuration file
  - Add the following section at the bottom of the file

```
[AllSky-01]
path = /home/{YourUserName}
writeable = yes
browseable = yes
public=no
```
  - Save & Exit [ctr-X] Y
- Setup user to access file share
  - `sudo smbpasswd -a {YourUserName}`
    - `{YourPassword}`
- Restart Samba Server
  - `sudo systemctl restart smb`
- In windows, Map new network drive with following values:
  - Folder: `\\AllSky-01\{YourUserName}`
  - Add login credentials when requested
- DONE!

### References:


- [How to setup a Raspberry Pi Samba Server](#)

# Allsky Setup Instructions

## AllSky Cam Enclosure Cooling Fan Software Installation

Install the application on the Pi5 to run the cooling fan for the enclosure.

Note: connection for the fan to the Pi5: The fan should be connected to pins 4,6 & 8 (see [Raspberry Pi5 Pin Out Diagram](#)).



- Remote into the Pi5 system with SSH
  - In SSH control
    - `git clone https://github.com/mklements/PWMFanControl.git`
    - `cd PWMFanControl`
    - `cp FanProportional.py ~/FanProportional.py`
    - `cp FanStepped.py ~/FanStepped.py`
    - `crontab -e` (Edit using nano and add the following line at the bottom of the file)
    - `@reboot python3 /home/pi/FanProportional.py &`
    - Save changes to crontab, remove the downloaded folder and reboot
      - `sudo rm -rf PWMFanControl`
      - `sudo shutdown -r now`
- DONE!

### References:

- The DIY Life: [Connecting a PWM Fan to a Raspberry Pi](#)
- Hacatronic.com: [Raspberry Pi5 Pin Out diagram](#)

# Allsky Setup Instructions

## Install Gparted Application to Format

Gparted is a free, graphic partition manager that is often used on Linux systems. It can be installed on Raspberry Pi via the package manager, and used to reformat the SD card as needed.

Note: You need to run this application from the desktop not the command line once it is installed.

### Install Gparted Application

- In the Terminal interface type the following commands  
Sudo apt update  
Sudo apt install gparted
- After following the online instructions Gparted should be installed on your system and is accessible via the desktop under | System Tools | GParted |
- DONE

### References:

- Raspberrytips.com: [How To Install & Use Gparted On Raspberry Pi \(Partition editor\)](#)

# Allsky Setup Instructions

## Backup Pi5 as a Disk Image

Instructions provided here outline the process of backing up your Pi5 to a image file that can be used to retore to a new usb drive utilizing the Raspberry Pi Installer on your local computer.

- Format a USB Flash or the best hard drive as NTFS
  - Drive Name: **Pi5Backup**
- Connect the drive to the Pi5
- Install pishrink.sh on the Pi5 and copy it to the /usr/local/bin folder
  - `wget https://raw.githubusercontent.com/Drewsif/PiShrink/master/pishrink.sh`
  - `sudo chmod +x pishrink.sh`
  - `sudo mv pishrink.sh /usr/local/bin`
- Check the mount point path of your USB drive
  - `lsblk`
    - `sda 8:0 1 953.6G 0 disk`
    - `└─sda1 8:1 1 953.5G 0 part /media/JamesJr/Pi5Backup`
- Copy your data to an img file by using the dd command
  - `sudo dd if=/dev/mmcblk0 of=/media/{YourUserName}/Pi5Backup/ImageName.img bs=1M`
- Navigate to the USB drive's root directory and list contents, your image file *ImageName* should be there.
  - `cd /media/{YourUserName}/Pi5Backup`
  - `ls -l`
- Use pishrink with the -z parameter, which zips your image up with gzip (this may take a few minutes). when it is done, you will end up with a reasonably sized image file called myimg.img.gz. You can copy this file to your PC and us it in the Raspberry Pi Imager application to image a new usb card.
  - `sudo pishrink.sh -z ImageName.img`
- Shutdown Pi5 and remove usb drive. You can now copy the .gz file to windows for utilizing in the Pi Imager to duplicate the card.

### References:

- [How to Backup Your Raspberry Pi as a Disk Image](#)

### Images

Name	Size	Summary
01-OSInstall.img.gz	1.8 GiB	Operating System, Fan Control, Sumba Server
02-AllskyInstall.img.gz	2.6 GiB	Allsky package install. No configuration
03-AllSkyConfig.img.gz	2.7 GiB	Allsky configuration for local server only


# Allsky Setup Instructions

## Remote Website Setup: Sub Domain Setup

Before we can install the Allsky website on the remote website we need to setup a sub-domain for the website to reside in. This involves the following steps:

- Create Directory Structure for Sub Domain
- Create the allSky Sub-Domain
- Create an Administrator Account to Manage the Sub-Domain

### Allsky Website Directory Structure



### Prerequisites

- Remote website and domain ownership

### Create Directory Structure for Sub Domain

- Log into the hosting website with the master account ([A2Hosting](#))
- In the [cPanel Quick Login] section select the ArtCentrics.com [cPanel Login] button to open the ArtCentrics [cPanel] page.
- In **cPanel** in the [Files] section select [File Manager] to open the File Manager application.
- In the **File Manager** application create the following folders:
  - /public\_html/**AllSkyCams**
  - /public\_html/AllSkyCams/**Yoder**
    - *Note: In this example the Yoder directory is the directory that will be used to house and administrate the allsky sub-domain. It is the parent directory to the allsky directory.*
  - /public\_html/AllSkyCams/Yoder/**allsky**
- DONE

# Allsky Setup Instructions

## Create the allsky Sub-Domain

- Log into the hosting website with the master account ([A2Hosting](#))
  - In the [cPanel Quick Login] section select the ArtCentrics.com [cPanel Login] button to open the ArtCentrics [cPanel] page.
  - In **cPanel** in the [Domains] section select [Domains] to open the Domains application.
  - In the **Domains** application select the [Create A New Domain] button to create a new sub-domain with the following values:
    - Domain: **allsky-yoder.artcentrics.com**
    - Document Root: **/public\_html/AllSkyCams/Yoder**
- DONE

## Create an Administrator Account to Manage the Sub-Domain

An account needs to be created that has the ability to add/remove directories and files to the folder (allsky) that will contain the website and associated files. This account should be separate from the Master account used to manage the parent domain and website. This task is completed by creating a ticket for the website hosting service.

- Log into the hosting website with the master account ([A2Hosting](#))
  - Select [Open Ticket] option
  - Create a ticket with the following information
    - I need a new ftp account setup to administrate the sub-domain “**allsky-yoder.artcentrics.com**” that resides at **/public\_html/AllSkyCams/Yoder**.
  - After the ticket has been submitted you should receive notification the task is complete. Make note of the login ID and password.
  - DONE

## Sub Domain Administration Account Information

- Protocol: **FTP**
- Login ID: **admin@allsky-yoder.artcentrics.com**
- Password: (*Provided by hosting service*)
- FTP Host Name: **az1-ss110.a2hosting.com**

Use FTP application such as [FileZilla client](#) to log into the account and verify the directory is available.

# Allsky Setup Instructions

## Remote Website Setup: Install Remote Website

These Instructions detail the process of migrating the allsky website to the remote website.

(This section is incomplete)

### Prerequisites

- Remote Website Setup: Sub Domain Setup – Remote Sub-Domain administrator account, file structure, and sub domain should have been created already.

### References

- Allsky Documentation: [Preparing a Remote Server](#)
- 

DRAFT